

Casement Internal Beaded_Drainage

Machine Drainage Slot 70mm from corner of glazing
@ minimum 400mm Centre

Seal Corner

Remove Weatherseal Locally

Drill hole under side of shah @ 300mm Centre

Equalize pressure within cavity.

